

User Manual




OPEN-SOURCE

BADGE


v0.2

COMMUNICATIONS

Exploded View



Layout



** Visual Appearance may vary*

Commands & Functions

After a **Tap** on the Main Capacitive GesturePad, counter of 10 seconds will begin, where **Listening mode** is active.


During **Listening Mode** speak one of the following to activate its function:

Command	Function
Call < NAME >	Calls Contact with matching name. Badge searches for Matching < BADGE-ID > from local Contacts list, Connects both Badges to a Private Channel.
Call BadgeID < BADGEID >	Calls specified BadgeID. (Speak Numbers Clearly & Single Tap when done)
*Add Contact (<i>Combined with Gesture & Chirp as method for sharing BadgeID</i>)	
*Translate to < LANGUAGE >	
Begin Recording / Start Recording	Starts recording for 20 seconds from microphone to microSD. Saved as .wav

** Not all features may be currently enabled*

Secondary Touch Button Functions

Button	Function
Middle Right	Function-Lock Key (SHIFT) Used to ensure no accidental activation of other buttons (HOLD to use)
Top Left	Contact Sharing Mode (See Gestures)
Middle Left	Mute
Bottom Left	On-Demand WIFI Configuration Access Point (Config-AP)



Gestures

A **Tap** on the **Main Gesture Pad** or **SHIFT** will wake up the ComBadge from sleep.

The Following **Gestures** are available while awake:

Gesture	Function
Swipe Up	Contact Sharing (<i>Send Mode</i>): Send Name & BadgelD via <i>Chirp</i> to Receiving Badge in <i>Receive Mode</i> . Normal Mode: Volume Up
Swipe Down	Contact Sharing (<i>Receive Mode</i>): Receive Name & BadgelD via <i>Chirp</i> from Sending Badge in <i>Send Mode</i> & Create New Contact → Speak <Name> Normal Mode: Volume Down
*Swipe Left	
*Swipe Right	
Tap	Waking Tap: Wakes up the ComBadge from sleep and activates <i>Listening Mode</i> <i>Tapping while Awake</i> has no function.
Double Tap	Already Awake: Deactivates <i>Listening Mode</i> or Closes Current Call

** Not all features may be currently enabled*